

- 1: Connect the lamp wires to the reserved wires
- 2: Fix the lamp body to the ceiling with self tapping screws
- 3: The lampshade is bent from the bottom and inserted into the lamp body

