




COZYEAZY.COM

SUPPORT@COZYEAZY.COM

L I G H T I N G



1



Press the top to adjust the height

Instructions for using the telescopic device

