


COZYEAZY.COM

SUPPORT@COZYEAZY.COM

L I G H T I N G



INSTALLATION INSTRUCTIONS

COZYEAZY.COM
SUPPORT@COZYEAZY.COM

CAUTION

Turn off the power to the main circuit panel before starting.

CAUTION

The light source for this product is a non-replaceable LED. Do not disassemble the product, as the LED may damage your eyes.

Do not immerse in water.



WARNINGS

Failure to follow assembly instructions may result in a fire or electric shock hazard.

CAUTION

Pulling the light fixture out of the surface may cause personal injury and damage to the fixture and/or the mounting surface. To reduce the likelihood of such injury or damage, install it only on surfaces with intact mechanical structures.



WARNINGS

Different materials require different fittings. Always select screws and plugs specifically matched to the material.



WARNINGS

Failure to follow assembly instructions may result in a fire or electric shock hazard.



WARNINGS



Choking hazard. Keep the power cord at least 3 feet away from cribs, bassinets, and toddler beds.



CARE AND MAINTENANCE


Handle with Care: Please exercise caution during assembly and cleaning to avoid scratches or breakage.

THIS PRODUCT IS NOT A TOY AND HAS NO PLAY VALUE.



⚠ IMPORTANT (US & Canada Only)

Due to the narrow profile of this fixture, the Round Cover Plate (included) must be installed to fully cover the standard Junction Box.



ISH
Live

ENGLISH
Neutral

FRANCAIS
Phase


FRANCAIS
Neutral


ESPAÑOL
Con
corriente.

ESPAÑOL
Neutro

Terre

ESPAÑOL
Tierra





5

COZYEAZY.COM

SUPPORT@COZYEAZY.COM

